



1. 功能表 → 按 ●



2. 設定 → 按 ●



3. 安全性 → 按 ●



4. 設定 SIM 卡鎖定 → 按 ●



5. 選擇 SIM1/SIM2

開啟 PIN 碼



6. 鎖定 SIM 卡 開啟 → 按 ●



7. 輸入 SIM PIN → 連接 ● 2 次



8. 完成

## 關閉 PIN 碼



6. 鎖定 SIM 卡 **關閉**  
→ 按 ●



7. 輸入 SIM PIN  
→ 連接 ● 2 次



8.  完成