

HYUNDAI_GD99 切換頻率



1. 功能表→按 ●



2. 設定→按 ●



3. 更多內容→按 ●



4. 行動網路→按 ●



5. 選擇 SIM1/SIM2



6. 偏好的網路類型
→按 ●



7. 自行選擇